



Digital Nose Milk Freshness Checker

Created by Carter Nelson



<https://learn.adafruit.com/digital-nose-gas-sensor-milk-freshness-checker>

Last updated on 2025-02-24 02:59:46 PM EST

Table of Contents

Overview	3
<ul style="list-style-type: none">• Hardware	
Background Information	5
<ul style="list-style-type: none">• Covid Related Loss of Smell• How Milk Spoils• Electrical Nose	
Build the Checker	7
CircuitPython on CLUE	8
<ul style="list-style-type: none">• Set up CircuitPython Quick Start!	
CLUE CircuitPython Libraries	11
<ul style="list-style-type: none">• Installing CircuitPython Libraries on your CLUE	
Code	12
<ul style="list-style-type: none">• Additional Libraries• Freshness Indication• Code	
Experiment	16
<ul style="list-style-type: none">• Adjusting the Code• Other Sensor Values• Other Sensors• Other Uses	

Overview



The classic method for testing for milk freshness is to give it a quick sniff check. If it smells "bad", then it probably is. This is great, as long as your sense of smell is working. But maybe covid, congenital anosmia, a stuffy cold, or something else has reduced your sense of smell. What then?

In this guide we investigate the potential for using a gas sensor as a way to test for milk freshness. An SGP30 and a CLUE are used to make a little "freshness checker" device. We then use this in a simple experiment to see if it can detect spoiled milk.



This project does NOT require any soldering and is a great little science experiment

Hardware

Here is a summary of the hardware needed for this project.



Adafruit CLUE - nRF52840 Express with Bluetooth LE

Do you feel like you just don't have a CLUE? Well, we can help with that - get a CLUE here at Adafruit by picking up this sensor-packed development board. We wanted to build some...

<https://www.adafruit.com/product/4500>



Adafruit SGP30 Air Quality Sensor Breakout - VOC and eCO2

Breathe easy with the SGP30 Multi-Pixel Gas Sensor, a fully integrated MOX gas sensor. This is a very fine air quality sensor from the sensor experts...

<https://www.adafruit.com/product/3709>




STEMMA QT / Qwiic JST SH 4-pin Cable - 100mm Long

This 4-wire cable is a little over 100mm / 4" long and fitted with JST-SH female 4-pin connectors on both ends. Compared with the chunkier JST-PH these are 1mm pitch instead of...

<https://www.adafruit.com/product/4210>

This is the battery shown in the guide:



Lithium Ion Polymer Battery - 3.7V 350mAh

Lithium-ion polymer (also known as 'lipo' or 'lipoly') batteries are thin, light, and powerful. The output ranges from 4.2V when completely charged to 3.7V. This...
<https://www.adafruit.com/product/2750>

but you can use any other similar lithium ion battery option:

Lithium Ion Batteries

<https://adafru.it/waX>

Background Information

In this guide we use the phrase "covid" and/or "coronavirus" to refer to the [Coronavirus disease 2019 \(COVID-19\)](https://adafru.it/O0B) as caused by the [severe acute respiratory syndrome coronavirus 2 \(SARS-CoV-2\)](https://adafru.it/QSb).

Covid Related Loss of Smell

The [CDC](https://adafru.it/O1a) list "New loss of taste or smell" as one the main [symptoms of covid](https://adafru.it/QSc). Sickness related loss of smell is nothing new, even the common cold can cause it to happen. However, due to the global pandemic scope of covid, this issue has received renewed and increased significance. There have been various news stories covering this issue and how it has impacted people's ability to "sniff" for dirty laundry, rotten food, etc.

We thought this issue would make for some great science and wanted to see if electrical sensors could be used. Here we share our results on making a milk freshness tester.

How Milk Spoils

We use the term "bad" to describe "spoiled" milk, but really it's just nature doing its thing. There are [numerous bacteria](https://adafru.it/QSd) that love milk. Unfortunately for us, their consumption of milk produces byproducts that we find distasteful and can even be harmful.

Spoilage is also a vague term. As this [paper](https://adafru.it/QSe) ([PDF](https://adafru.it/QSf)) puts it:

Milk spoilage is an indefinite term and difficult to measure with accuracy.

This paper summarizes various techniques that have been investigated as a way to detect spoilage, including:

- pH
- electrical methods
- magnetoelastic sensors
- gas sensor arrays
- infrared spectroscopy
- protein count

It is the **gas sensor** based approach we are interested in here. This is analogous to what we do when we sniff milk to check freshness. Our noses are essentially gas sensors. But if covid (or something else) has knocked out your sense of smell, then your gas sensor is broken. Can we use an electrical gas sensor instead?

Electrical Nose

The general of idea of gas sensor based milk spoilage detection has been investigated by others.


- [Application of gas-sensor array technology for detection and monitoring of growth of spoilage bacteria in milk: A model study. \(https://adafru.it/QSA\)](https://adafru.it/QSA)
 - Evaluation based on change over time.
- [Milk-sense: a volatile sensing system recognises spoilage bacteria and yeasts in milk. \(https://adafru.it/QSB\)](https://adafru.it/QSB)
 - Conducting polymer detector for microbial volatiles.

There are various gases that are discussed amongst these papers, but a common approach is to use microbial produced volatile organic compounds (VOCs) and carbon dioxide (CO₂). Well, the [SGP30 from Sensirion \(https://adafru.it/QSC\)](https://adafru.it/QSC) , as used on the [Adafruit SGP30 STEMMA QT breakout \(http://adafru.it/3709\)](http://adafru.it/3709), can detect both of these.


So can the SPG30 be used to create an "electric nose"? Well, let's science this and find out.

Build the Checker


Let's start by putting together our CLUE Milk Freshness Checker. The CLUE and SGP-30 are the key parts. For the other items, we used some things that can hopefully be found laying around the house. If not, feel free to substitute for whatever is available to achieve the same general arrangement.




- CLUE board
- SGP-30 sensor
- Battery
- Stemma QT cable
- Popsicle stick
- Double sided tape
- Rubber band




Put a piece of double sided tape about the same size as the SGP-30 at one end of the popsicle stick.



Place the SGP-30 firmly onto the double sided tape and attach the Stemma QT cable.



Use the rubber band to secure the CLUE and battery to the other end of the popsicle stick.



Plug in the Stemma QT cable and battery.

Do NOT let the SGP-30 touch the milk. It is not a moisture proof sensor.

Now move on to setting up the CLUE for CircuitPython usage and loading the code. It comes with some preset values we determined in our testing. We'll cover how you can alter these later.

CircuitPython on CLUE

[CircuitPython \(https://adafru.it/tB7\)](https://adafru.it/tB7) is a derivative of [MicroPython \(https://adafru.it/BeZ\)](https://adafru.it/BeZ) designed to simplify experimentation and education on low-cost microcontrollers. It makes it easier than ever to get prototyping by requiring no upfront desktop software downloads. Simply copy and edit files on the **CIRCUITPY** flash drive to iterate.

The following instructions will show you how to install CircuitPython. If you've already installed CircuitPython but are looking to update it or reinstall it, the same steps work for that as well!

Set up CircuitPython Quick Start!

Follow this quick step-by-step for super-fast Python power :)

Download the latest version of
CircuitPython for CLUE from
circuitpython.org

<https://adafru.it/IHF>




Click the link above to download the latest version of CircuitPython for the CLUE.

Download and save it to your desktop (or wherever is handy).


Plug your CLUE into your computer using a known-good USB cable.

A lot of people end up using charge-only USB cables and it is very frustrating! So make sure you have a USB cable you know is good for data sync.




Double-click the **Reset** button on the top (magenta arrow) on your board, and you will see the NeoPixel RGB LED (green arrow) turn green. If it turns red, check the USB cable, try another USB port, etc. **Note:** The little red LED next to the USB connector will pulse red. That's ok!

If double-clicking doesn't work the first time, try again. Sometimes it can take a few tries to get the rhythm right!




You will see a new disk drive appear called **CLUEBOOT**.



Drag the **adafruit-circuitpython-clue-etc.uf2** file to **CLUEBOOT**.

The LED will flash. Then, the **CLUEBOOT** drive will disappear and a new disk drive called **CIRCUITPY** will appear.



If this is the first time you're installing CircuitPython or you're doing a completely fresh install after erasing the filesystem, you will have two files - **boot_out.txt**, and **code.py**, and one folder - **lib** on your **CIRCUITPY** drive.

If CircuitPython was already installed, the files present before reloading CircuitPython should still be present on your **CIRCUITPY** drive. Loading CircuitPython will not create new files if there was already a CircuitPython filesystem present.

That's it, you're done! :)

CLUE CircuitPython Libraries

The CLUE is packed full of features like a display and a ton of sensors. Now that you have CircuitPython installed on your CLUE, you'll need to install a base set of CircuitPython libraries to use the features of the board with CircuitPython.

Follow these steps to get the necessary libraries installed.


Installing CircuitPython Libraries on your CLUE

If you do not already have a **lib** folder on your **CIRCUITPY** drive, create one now.


Then, download the CircuitPython library bundle that matches your version of CircuitPython from [CircuitPython.org](https://circuitpython.org).

Download the latest library bundle
from circuitpython.org


<https://adafru.it/ENC>



The bundle downloads as a .zip file.
Extract the file. Open the resulting folder.




Open the **lib** folder found within.



Once inside, you'll find a lengthy list of folders and .mpy files. To install a CircuitPython library, you drag the file or folder from the **bundle lib** folder to the **lib** folder on your CIRCUIPTY drive.

Copy the following folders and files **from** the **bundle lib** folder to the **lib** folder on your CIRCUIPTY drive:



adafruit_apds9960
adafruit_bmp280.mpy
adafruit_bus_device
adafruit_clue.mpy
adafruit_display_shapes
adafruit_display_text
adafruit_lis3mdl.mpy
adafruit_lsm6ds
adafruit_register
adafruit_sht31d.mpy
adafruit_slideshow.mpy
neopixel.mpy

Your lib folder should look like the image on the left. These libraries will let you run the demos in the CLUE guide.

Code

Here's how to load the code and assets as well as some additional libraries you'll need.

Additional Libraries


In **addition** to the main libraries needed for CLUE support covered in the previous section, you'll also need to install the libraries listed here.

You can download the latest library bundle from the [CircuitPython webpage \(https://adafru.it/ENC\)](https://adafru.it/ENC).

Make sure you have a copy of these in your **CIRCUITPY/lib** folder.

- `adafruit_bitmap_font`
- `adafruit_imageload`
- `adafruit_sgp30.py`


Here's a summary:




Name	Size	Modified
adafruit_apds9960	3 items	15 Feb
adafruit_bitmap_font	6 items	15 Feb
adafruit_bus_device	3 items	15 Feb
adafruit_display_shapes	7 items	15 Feb
adafruit_display_text	3 items	15 Feb
adafruit_imageload	4 items	15 Feb
adafruit_lsm6ds	5 items	15 Feb
adafruit_register	7 items	15 Feb
adafruit_bmp280.mpy	8.6 kB	14 Feb
adafruit_clue.mpy	9.8 kB	14 Feb
adafruit_lis3mdl.mpy	5.5 kB	14 Feb
adafruit_sgp30.mpy	3.1 kB	14 Feb
adafruit_sht31d.mpy	7.4 kB	14 Feb
adafruit_slideshow.mpy	8.5 kB	14 Feb
neopixel.mpy	1.9 kB	14 Feb

Freshness Indication


The code below comes with preset values for `TVOC_LEVELS` used to determine milk freshness. In the next section we discuss the experiment we ran to determine these values as well as how you can alter them. Once set, the CLUE display will indicate milk "freshness" as follows:



GOOD + smiling cow = the TVOC levels are very low, so milk should be good.



SUS? + confused cow = the TVOC levels are high enough that the milk may be starting to turn.



BAD! + frowning cow = the TVOC level are high enough the milk should be considered bad.

Code

Use the **Project ZIP** link below to download the code as well as the bitmaps and font files used in a single zip file.

Drag the entire **bmps** and **fonts** folders to your **CIRCUITPY** folder. These assets will live in those subfolders.

Save the code listing as **code.py** into your **CIRCUITPY** folder so it will run automatically when powered up.

```
# SPDX-FileCopyrightText: 2021 Carter Nelson for Adafruit Industries
#
# SPDX-License-Identifier: MIT

import time
import board
import displayio
import adafruit_sgp30
from adafruit_bitmap_font import bitmap_font
from adafruit_display_text import label
import adafruit_imageload
from adafruit_clue import clue

# --| User Config |-----
TVOC_LEVELS = (80, 120) # set two TVOC levels
```

```

MESSAGES = ("GOOD", "SUS?", "BAD!") # set three messages (4 char max)
# -----

# setup UI
cow_bmp, cow_pal = adafruit_imageload.load("bmps/milk_bg.bmp")
background = displayio.TileGrid(cow_bmp, pixel_shader=cow_pal)

mouth_bmp, mouth_pal = adafruit_imageload.load("bmps/mouth_sheet.bmp")
mouth = displayio.TileGrid(
    mouth_bmp,
    pixel_shader=mouth_pal,
    tile_width=40,
    tile_height=20,
    width=1,
    height=1,
    x=35,
    y=110,
)

msg_font = bitmap_font.load_font("fonts/Alphakind_28.bdf")
msg_font.load_glyphs("".join(MESSAGES))
message = label.Label(msg_font, text="WAIT", color=0x000000)
message.anchor_point = (0.5, 0.5)
message.anchored_position = (172, 38)

data_font = bitmap_font.load_font("fonts/F25_Bank_Printer_Bold_12.bdf")
data_font.load_glyphs("eTVOC=12345?")
tvoc = label.Label(data_font, text="TVOC=?????", color=0x000000)
tvoc.anchor_point = (0, 1)
tvoc.anchored_position = (5, 235)

eco2 = label.Label(data_font, text="eCO2=?????", color=0x000000)
eco2.anchor_point = (0, 1)
eco2.anchored_position = (130, 235)

splash = displayio.Group()
splash.append(background)
splash.append(mouth)
splash.append(message)
splash.append(tvoc)
splash.append(eco2)
clue.display.root_group = splash

# setup SGP30 and wait for initial warm up
i2c = board.I2C() # uses board.SCL and board.SDA
# i2c = board.STEMMA_I2C() # For using the built-in STEMMMA QT connector on a
# microcontroller
sgp30 = adafruit_sgp30.Adafruit_SGP30(i2c)
time.sleep(15)

# loop forever
while True:
    eCO2, TVOC = sgp30.iaq_measure()

    tvoc.text = "TVOC={:5d}".format(TVOC)
    eco2.text = "eCO2={:5d}".format(eCO2)

    level = 0
    for thresh in TVOC_LEVELS:
        if TVOC <= thresh:
            break
        level += 1


    if level <= len(TVOC_LEVELS):
        message.text = MESSAGES[level]
        mouth[0] = level
    else:
        message.text = "?????"

```

```
time.sleep(1)
```


Experiment

Here is the simple experiment we ran to determine the specific SPG-30 sensor values used in the code.



The experiment was carried out during February 2021 with the milk shown.

Data was collected February 28, 2021.




Each day, a small amount of milk was poured into a glass and labeled with the current date. This was done for 5 days to produce a series of milk of differing ages.



We used the code to provide a readout of the SGP-30's TVOC and eCO₂ - the values shown in the grass at the bottom of the display.

At this point, don't worry about what the cow says.

Do NOT let the SGP-30 touch the milk. It is not a moisture proof sensor.



For each sample, we lowered the sensor into the glass **without touching the milk**, slowly moved it around, and watched the readings for about **1 minute**.

We then wrote down the observed range for each gas reading.

Here is a summary of the readings we obtained:

DAYS	TVOC	eCO2
0	40-60	500-700
1	110-130	600-700
2	160-200	700-900
3	300-900	1500-2100
4	1500-3000	3000-10000

Now we have values we can use in our code to determine milk freshness. We considered there to be three levels:

- **GOOD** - low readings very close to fresh milk
- **SUS?** - the readings are slightly elevated, milk is sus
- **BAD!** - milk that has obviously gone bad

Based on the values we observed, we decided on **TVOC <= 80** as the cutoff for **GOOD**, **TVOC <= 120** as the cutoff for **SUS**, and anything above that as **BAD!**

However, different milk may age in different ways. Different environmental conditions, like temperature and humidity, may also affect the readings. Further, your personal level of comfort on what constitutes "bad" milk, may be different than others. Therefore, we suggest you repeat the above experiment.

We suggest you repeat this experiment!

Adjusting the Code

You can easily adjust the code to change the cutoff TVOC levels used for freshness detection. You can even customize what the cow says. Just look for these lines at the top of the code:

```
# --| User Config |-----  
TVOC_LEVELS = (80, 120) # set two TVOC levels  
MESSAGES = ("GOOD", "SUS?", "BAD!") # set three messages (4 char max)  
# -----
```

and change as needed. Note there are only two TVOC levels to specify for a total of three freshness levels.

Other Sensor Values

We decided to keep things simple and just use the SGP-30's TVOC reading. But note in the data above that eCO2 also increased with milk age. This production of CO2 is mentioned in the research papers previously cited. Perhaps a more sophisticated approach could be used that take both readings into account? **We leave that up to any intrepid scientist out there that wishes to investigate further.**

Other Sensors

We tried a few other sensors as well but they did not seem to have any useful "milk freshness" related signal. At least nothing with as good a signal-to-noise ratio as the SGP-30.

- [SGP-40 \(http://adafru.it/4829\)](http://adafru.it/4829)
- [BME680 \(http://adafru.it/3660\)](http://adafru.it/3660)

Other Uses

We also thought this idea could be used for detecting dirty laundry. However, that did not seem to work - at least not as easy as the approach above for milk. This may be due to the various dyes used to color clothing producing VOCs that mask any similar signal from "dirty" smells.